

## Focus ST/RS Traction Bar Installation Guide

- 1.) Put your vehicle in the air via a set of ramps. You'll want to have your car on ramps because the suspension must be loaded during installation.
- 2.) Once the vehicle is in the air, begin by removing your under tray using a t-30 torx bit.
- 3.) With the cover off we can see the two horizontal Lower Control Arm bolts. Remove these using an 18mm. Warning: sometimes these bolts are EXTREMELY tight. be ready with an air impact gun or your favorite redneck that runs on nicotine and hate with a breaker bar.
- 4.) Bolt the traction bar on ensuring that you have enough clearance between your charge pipes. While not required, some people like to replace the oem bolts with new ones. the part number is W715485S442
- 5.) Torque both bolts down to 110 ft lbs+90\* this means that you will torque the bolt to 115 ft lbs and then continue to tighten the bolt another 1/4 turn.
- 6.) Reinstall the splash cover and go send it hard in the twisties!